



Extent of delivery

- On/off button
- Light capsule headO-Ring gasket
- Batteries
- PLight capsule body
- · Light capsule holder



How to install the batteries

- 1. Screw off the orange head.
- 2. Place the 3 batteries in the orange head (order does not matter). The protective film shall be removed before installing the batteries.
- 3. Screw the orange head back into the black body of the light capsule.

How to operate

Once the batteries are in, press the on/off button once to turn the light capsule on. Press the on/off button a second time to turn the light off.

Maintenance and precautions

- When replacing the batteries, it is recommend to use high quality batteries to preserve the life of your light capsule.
- Do not point the light directly in the eyes to avoid injury.
- Keep the light capsule out of direct sunlight, water, chemicals or corrosive gas for extended periods of time to avoid damages.
- It is recommended to lubricate the threads 2-3 times year to ensure smooth screwing and unscrewing of the orange head.
- To clean the light capsule, use a soft brush or towel.
- To avoid corrosion, it is recommended to remove the batteries when not in use for extended periods of time.
- Seek professional help when dissembling the contents beyond changing the batteries of light capsule to prevent damage.





facebook.com/Luminox



@luminoxworld



You Tube youtube.com/LuminoxWorld